


STEP-1 : setup SPKDSPV2setup.exe


1. open exe file as right



2. you will open as the following page



3. click "NEXT" as left picture



4. Choose as below picture, and click "下一步(N)"



5. click "下一步(N)" as below picture



6. choose the right place at your computer and click "下一步(N)"



7. choose "下一步(N)" to continue



8. choose "下一步(N)" to start installing now



9. if the following page come, click as the picture, until this page finishing installing (next page will come out)




10. after the above step, you can find this software at PC-START



see next page

STEP-2. open file as below pictures





now, you can find the "DSP-2IN4OUT V1.0" at your PC-START, as left picture, open it, will come with below page



operate at "file" or "tools"



the end
wish it's helpful for you